

# navi2coach

## Why does the navi2coach turn itself off?

If your navi2coach is not connected to an ANT+sensor, you didn't start a recording and no button has been used for more than ten minutes, the navi2coach will turn itself off for power-saving.

To avoid this, please push the start/stop button and start a recording.

Unique solution ID: #1146

Author: o-synce support team

Last update: 2013-07-19 12:01