

navi2coach

My device has no reception, what can I do?

- If there is no GPS signal, your navi2coach still has to search a satellite. This works best when the device is kept motionless and positioned in the open. This implies: it takes longer to receive a signal if you are situated in a street canyon than on an open place or on a field. If you are positioned in a street canyon and want to accelerate the satellite search, try to position yourself at a place where there are less high buildings.
- If the device is fixed to a bike, please avoid to touch it with your hands as you may cover the antenna which may delay the satellite search.
- Under menu item **Navigation -> GPS Position** the signal strength is displayed. If the value is below 37, it may take some minutes until a GPS signal is found (acquiring a satellite needs a better signal strength than tracking a satellite).

Hint: Depending on your surrounding, the satellite search may take some minutes.

TIP: To be sure to have GPS reception when you start your tour, turn the device on and put it on a window sill while you're preparing yourself for the bike.

Unique solution ID: #1100

Author: o-synce support team

Last update: 2013-05-07 16:04