

I can not read the status bar!

You might want to decrease the display contrast if the background is too dark. You can do that directly on the device in the Display Setup menu.

Select the following menu items

Setup-> System -> Display -> Contrast

and adjust the contrast.

Unique solution ID: #1108

Author: o-synce support team

Last update: 2013-05-07 14:33