

How do I delete a course in my device?

Connect your navi2coach to your PC or MAC and select the folder **Courses** which you find in the device directory. Delete the course from the directory.

Unique solution ID: #1107

Author: o-synce support team

Last update: 2013-01-19 18:07