

navi2move

Mouse cursor starts to jump when NAVI2move is connected

If the cursor of your computer mouse starts jumping when the Navi2move is connected to your PC, then the reason is that it has been recognized as a mouse.

With the current firmware update you may solve the problem. The update and the manual may be found on the following page: [o-synce Navi2move firmware update](#)

Unique solution ID: #1034

Author: o-synce support team

Last update: 2010-11-03 19:00