

macrox

How to switch from bike 1 to bike 2?

For switching in between the saved bikes, please proceed the following:

1. Access the menu “average speed” (**AVG**) in the lowest display line. Now you should see **AVG** and a small cyclist above the lowest display line.
2. Press the upper button and hold it for 2-3 seconds. Now the MACRO will change from bike 1 to bike 2 and backwards.

Which bike you are currently using is shown by the number “**1**” or “**2**” which is displayed above the temperature.

Unique solution ID: #1016

Author: o-synce

Last update: 2013-11-26 15:37