

macrohigh x

After a break (20-30 minutes) the speedometer failed to measure the speed again when I wanted to continue my trip. It displayed " - - "

This is a quite normal behavior of the macro bike computer. When you take a break the sensor goes into sleep mode after a while. It wakes up again when moving the bike but the head unit won't find it directly. The automatic searching takes place every 6 minutes (for saving energy it can't be more often). To avoid this gap you can do a manual searching (press the lower and the middle button at the same time). The sensor will be detected directly and speed will be shown on your macro computer immediately.

Unique solution ID: #1068

Author: o-synce support team

Last update: 2011-12-07 12:13