

coachsmart LEV

The connection between the USEE/coachsmart and apps like Naviki or o-synce mobile is faulty. What can I do?

USEE/coachsmart shows, despite purchased navigation instructions, no turning instructions of the Naviki App? The o-synce mobile app does not record sensor data?

Problems like this can occur if the USEE/coachsmart is paired directly within the operating system.

To solve the problem, the USEE/coachsmart on Android must be removed in the Bluetooth settings. Afterwards, the smartphone must be switched off and then switched on again. Pairing with the USEE/coachsmart is no longer done via the Bluetooth menu of the operating system, but directly via the settings menu of the respective app.

Examples:

Naviki: Settings -> Smart Bike System -> Smart Display

o-synce mobile: Edit bike profile -> Sensors -> Coachsmart

Unique solution ID: #1229

Author: Eliska Mastrakova

Last update: 2018-08-31 10:10